

[AN003]



ADVANCED
NETWORK DEVICES

Add an AND Device as a SIP Device in Call Manager

Version 2.1

6/7/2018

© 2018 ADVANCED NETWORK DEVICES

3820 NORTH VENTURA DR.

ARLINGTON HEIGHTS, IL 60004

U.S.A

ALL RIGHTS RESERVED

PROPRIETARY NOTICE AND LIABILITY DISCLAIMER

The information disclosed in this document, including all designs and related materials, is the valuable property of Digital Advanced Network Devices and/or its licensors. Advanced Network Devices and/or its licensors, as appropriate, reserve all patent, copyright and other proprietary rights to this document, including all design, manufacturing, reproduction, use, and sales rights thereto, except to the extent said rights are expressly granted to others.

The Advanced Network Devices product(s) discussed in this document are warranted in accordance with the terms of the Warranty Statement accompanying each product. However, actual performance of each product is dependent upon factors such as system configuration, customer data, and operator control. Since implementation by customers of each product may vary, the suitability of specific product configurations and applications must be determined by the customer and is not warranted by Advanced Network Devices.

To allow for design and specification improvements, the information in this document is subject to change at any time, without notice. Reproduction of this document or portions thereof without prior written approval of Advanced Network Devices is prohibited.

Static Electric Warning



TROUBLESHOOTING AND ADDITIONAL RESOURCES

Complete Support Site with User Guides & Help: <http://www.anetdsupport.com/>
Additional App Notes: <http://www.anetdsupport.com/AppNotes>
Customer Feedback Survey: <http://www.anetdsupport.com/survey>
AND Legal Disclaimer: <http://www.anetd.com/legal>

CISCO UNIFIED CALL MANAGER (CUCM) SETUP

1. Log into CUCM web interface.
2. Create an End User account.
 - a. Under the *User Management* menu, select *End User*.
 - b. Click the *Add New* button, and enter End User information

<i>User ID</i>	Create a user name (e.g., Dan)
<i>Password</i>	Enter and confirm
<i>PIN</i>	Enter and confirm (Matches the <i>Password</i>)
<i>Last Name</i>	User last name

- c. Click the *Save* button.
3. Create a new phone entry for your device.
 - a. Under the *Device* menu, select *Phone*.
 - b. Click the *Add New* button.
 - c. Select *Phone Type* as *Third-party SIP device (Basic)*, then click *Next*.
 - d. Select the *Is Active* checkbox, if present.
 - e. Enter the following information:

<i>AND Device MAC address</i>	e.g., 2046F9010203
<i>Device Pool</i>	Default
<i>Phone Button Template</i>	Third-party SIP device (Basic)
<i>Owner User ID</i>	User ID (previously created, e.g., Dan)
<i>Device Security Profile</i>	Third-party SIP device Basic - Standard SIP Non-secure Profile
<i>SIP Profile</i>	Standard SIP Profile
<i>Digest User</i>	User ID (previously created, e.g., Dan)

- f. Click the *Save* button.
4. Assign a directory number.
 - a. At the left side of the newly created *Phone*, select the *Line [1] – Add a new DN* link.
 - b. Add a *Directory Number* (e.g., 7003).
 - c. Click the *Save* button.
 5. Verify the Phone License Feature has units remaining (Select **System** → **Licensing** → **License Unit Report**). Each SIP device requires three units.

AND DEVICE SETUP

Option 1 – Configuration via AND Device Web Page

1. On the AND device's web page, select **Device Settings** → **SIP**.
2. Enter the following information:

<i>Extension</i>	Match the <i>Directory Number</i> used in the <i>Phone</i> device (e.g., 7003)
<i>SIP Server</i>	Match the IP address of the CUCM server
<i>SIP Domain</i>	Leave blank
<i>SIP Password</i>	Match the password entered in the <i>End User</i> profile
<i>SIP Digest Username</i>	Match the <i>Digest User</i> entered in the <i>Phone</i> device (e.g., Dan)



Home Device Status SIP Status **Device Settings**


General Audio Display Network **SIP** SIP2 Servers Firmware Peripherals Streams Priorities Scheduler XML

Changed settings have been saved and applied.

SIP General Settings [help](#)

Parameter	Stored value	New Value
SIP Mode	Phone	Phone ▾
Promiscuous Mode	Yes	Yes ▾
Extension	7003	7003
SIP Server	10.10.7.168	10.10.7.168
SIP Domain (e.g. digidescorp.com)		
SIP Password	password123	password123
SIP Digest Username	Dan	Dan

3. If using the optional push-button to generate a callback to another SIP device, set the *Push-To-Talk 1* to the extension of the line to ring when the button is pressed. Alternately, you can specify the MAC address or IP address of another AND device instead of an extension.



SIP GPIO Input Action Settings [help](#)

Parameter	Stored value	New Value
Push-to-Talk 1 (GPIO 0 Outgoing)	7000	7000
Push-to-Talk 1 Alternate (Hold)		
Push-to-Talk 1 Alternate Hold Time (ms)	0	0
Push-to-Talk 1 Trigger Only	No	No ▾

4. Click the *Save SIP Changes* button.
5. Reboot the device to begin using the new settings.

Option 2 – Configuration via Hosted Settings File

Global Configuration File Option

1. Edit the global configuration file (e.g., *IPSpeaker.cfg* or *InformaCastSpeaker.cfg*) to set the IP address of the CUCM server and point to the aggregate speaker configuration file that will contain the specific SIP information for each AND device on the network:

<i>SIP_server_addr</i>	CUCM server IP address
<i>AggregateSpeakerConfigFile</i>	File containing device-specific information

Example excerpt from *IPSpeaker.cfg*:

```
<SIPConfig
  SIP_server_addr="10.10.7.168"
/>
<AggregateSpeakerConfigFile file="AllSpeakers.cfg" />
```

2. Edit the aggregate speaker configuration file (e.g., *AllSpeakers.cfg*) to set the specific SIP information for each AND device on the network:

<i>id</i>	Match the <i>Directory Number</i> entered in the <i>Phone</i> device (e.g., 7003)
<i>password</i>	Match the password entered in the <i>End User</i> profile
<i>digest_username</i>	Match the <i>Digest User</i> entered in the <i>Phone</i> device (e.g., Dan)
<i>push_to_talk_ip1</i>	(optional) If using the push-button to generate a callback to another SIP device, set this parameter to the extension of the line to ring when the button is pressed. Alternately, you can specify the MAC address or IP address of another AND device instead of an extension.

Example excerpt from *AllSpeakers.cfg*:

```
<AllSpeakers>
  <Speaker mac="2046f9010203">
    <SIPConfig
      id="7003"
      password="password123"
      digest_username="Dan"
      push_to_talk_ip1="7000"
    />
  </Speaker>
</AllSpeakers>
```

3. Reboot the AND device to begin using the new settings.

MAC-Specific File Option

1. Edit the AND device's specific configuration file, *IPSpeaker2046f9010203.cfg*, where 2046f9010203 is the MAC address of the device to configure.
2. In the *SIPConfig* tag, set the following parameters:

<i>id</i>	Match the <i>Directory Number</i> entered in the <i>Phone</i> device (e.g., 7003)
<i>SIP_server_addr</i>	CUCM server IP address
<i>password</i>	Match the password entered in the <i>End User</i> profile
<i>digest_username</i>	Match the <i>Digest User</i> entered in the <i>Phone</i> device (e.g., Dan)
<i>push_to_talk_ip1</i>	(optional) If using the push-button to generate a callback to another SIP device, set this parameter to the extension of the line to ring when the button is pressed. Alternately, you can specify the MAC address or IP address of another AND device instead of an extension.

3. Reboot the AND device to begin using the new settings.

Example excerpt from *IPSpeaker2046f9010203.cfg*:

```
<IPSpeakerConfiguration>
...
<SIPConfig
  id="7003"
  SIP_server_addr="10.10.7.168"
  password="password123"
  digest_username="Dan"
  push_to_talk_ip1="7000"
/>
...
</IPSpeakerConfiguration>
```

OPERATION

The AND device should register with CUCM as a SIP device. Confirm this via the *SIP Status* section of the *SIP Status Page*, accessible from the device's web page.